

# SB202

VIRTUAL CERTIFICATION



In order to prepare for your dry run, please review the items and camera angles that are below. We ask that there be no more than (2) testers to (1) camera for the written examination to ensure we can see each technician and laptop clearly. Please mark your camera angles with blue tape prior to your dry run appointment. If you are unable to effectively complete a dry run, any items that were not successfully checked will be your responsibility to take care of prior to your virtual class date. This dry run process helps both the technician and the instructor create a better testing environment and ensures the best possible virtual class experience.

## Connection (Download Zoom Application)

- Video
- Audio
- Constant Connection

## Setup

- Clean Testing Space with minimum interruptions
- Tripod/Cell Phone Mount Placement
- Computer/Laptop and Equipment Placement

## Equipment – SB202

### Tex-117-E

- Triaxial cell for base material, lightweight stainless-steel cylinder fitted with standard air valve and tubular rubber membrane.
- Aspirator or other vacuum pump
- Air compressor
- Automated load frame or screw jack press
- Pressure regulator, gauges and valves to produce the lateral pressure
- Equipment to measure deformation of specimen, accurate to 0.001 in.
- Proving ring (for screw jack)
- 10K load cell
- Circumference measuring device, accurate to 0.05 in.
- Lead weights, for surcharge loads
- Curing pans, at least 2 in. deep with porous plates
- Filter paper with medium flow porosity
- Non-porous paper discs
- 2 (Tex-113-E) molded specimen, 6" diameter x 8" height

## Camera Angles

