

SB201

VIRTUAL CERTIFICATION



In order to prepare for your dry run, please review the items and camera angles below. We ask that there be no more than (2) testers to (1) camera for the examination to ensure we can see each technician and laptop clearly. Please mark your camera angles with blue tape prior to your dry run appointment. If you are unable to effectively complete a dry run, any items that were not successfully checked will be your responsibility to take care of prior to your virtual class date.

CONNECTION (DOWNLOAD ZOOM APPLICATION)

- Video Audio Constant connection

SETUP

- Clean testing space with minimum interruptions
 Tripod/cell phone mount placement
 Computer/laptop and equipment placement

EQUIPMENT

Tex-113-E


- Automatic Compaction Device equipped with the TxDOT approved Soil Compactor Analyzer
 6" compaction mold, base plate & collar
 10 lb slide finishing hammer
 Mixing pans/bowls with lids
 6" porous stone & non-porous paper disc
 Putty knife, spatula, brush, rubber mallet, & bubble level
 Hydraulic jack press - sample extruder
 Scale
 7/8" Sieve
 Flex base pre-sieved for recombining (at least 18 lbs)
 Sprinkler jar & water

Tex-114-E

- Automatic Compaction Device
 4" or 6" compaction mold, base plate & collar
 4" or 6" porous stone & non-porous paper disc
 Subgrade material at least 6 lbs. (for 4" mold) or approx. 22 lbs. (for 6" mold)

Pre-mix the materials with your estimated moisture

CAMERA ANGLES



Test



Tex-113-E



Tex-113-E



Tex-113-E



Tex-113-E



Tex-113-E



Tex-114-E



Tex-114-E

CAMERA ANGLES



Tex-114-E



Tex-114-E